



Congratulations. You are now the owner of a set of four borosilicate glass containers from Electrolux, a global leader in functional, beautiful, and sustainable home appliances designed for better living.

Product features

Learn more about the many benefits of your glass containers and read some important information on product care and safety.

Product features

Safe, healthy food preservation

Glass perfectly preserves food for tastier, healthier eating, while the BPA-free plastic lids ensure safe food storage. These glass containers are conveniently stain resistant making light work of cleaning and are also dishwasher-safe.

Seal in freshness, flavour and nutrients

The hermetic seal with silicone ring, with a valve for releasing steam, preserves food's flavour and retains nutrients for longer periods of time, which also helps reduce waste for more sustainable living.

Optimise your organisation

The glass containers' intelligent design with stackable sizes facilitate organisation in your fridge and pantry, for efficient meal preparation and functional food storage.

Versatile and durable

The highly practical borosilicate glass containers are resistant to extreme temperatures, making them ideal for freezer, electrical oven and microwave (without lid), as well as your fridge. These durable containers can withstand heat up to 400 C.



Safety guidelines

<u>CAUTION</u> - do not place containers directly on hot cooktop, or over an open flame.

- Discontinue use if product is chipped, cracked or scratched.
- · Avoid cleaning with a steel-wool scourer, or nylon sponge.
- · Containers are dishwasher safe. Warning: only wash lids on a dishwasher's top shelf.
- Deep clean containers occasionally by removing the lids' silicone ring.
- Remove lid for microwave use. The recommend maximum time in microwave is 20 minutes.
- · Containers can withstand heat up to 400°C.
- Do not use to store liquids in freezer as volume expansion may crack or break the glass.